

AEROMIC INSTRUCTIONS

"Over-the-Head Style"



Figure 1

To properly fit your Aeromic AM-10 Headset, first try on the Aeromic by placing frame behind left ear (figure 1) and then swing frame around the front of your face to place behind the right ear (figure 2).



Figure 2

If the mic does not fit properly, you may bend the frame to adjust the fit. Do so by gently bending the frame with two hands (figure 3). Then position the mic boom arm by gently bending using two fingers and thumb of both hands (figure 4). Remember! This is the most severe bend in the frame. Bend it very slowly and avoid right angles! Also: **DO NOT BEND YELLOW PART OF THE FRAME!!** Proper fit should feel snug and both rubber pads should touch the skin behind the

Figure 3





Figure 4



**DO NOT BEND
YELLOW PART
OF FRAME!**

IMPORTANT: Keep all angles gradual. Do not bend frame at sharp, right angles!

Gently plug and unplug connector from transmitter (figure 5). **DO NOT TWIST!**

Figure 5

