

# AEROMIC INSTRUCTIONS

## "Presenter Style"



Figure 1

To properly fit your Aeromic AM-10 Headset, first try on the Aeromic by allowing frame to surround your right ear (figure 1) and placing the frame on top of the left ear (figure 2).



Figure 2

If the mic does not fit properly, you may bend the frame to adjust the fit. Do so by gently bending the frame with two hands (figure 3). Then position the mic boom arm by gently bending using two fingers and thumb of both hands (figure 4). Remember! This is the most severe bend in the frame. Bend it very slowly and avoid right angles! Also: **DO NOT BEND YELLOW PART OF THE FRAME!!** Proper fit should feel snug and both rubber pads should touch the skin behind the ears. If the fit is not comfortable, re-bend the frame to match your head shape.





Figure 3

Figure 4



**IMPORTANT:** Keep all angles gradual. Do not bend at sharp, right angles!

Gently plug and unplug connector from transmitter (figure 5). **DO NOT TWIST!**

Figure 5

